








TRIAX ARMORED II
chrono



NOTE: The Chronograph will stop and reset after one hour


TRIAx ARMORED II
chrono

If the stopwatch dial hands do not return to "0" position, pull Crown to second click for calibration






NOTE: The MINUTES dial moves one minute for every 60 second revolution of the SECONDS dial

If the stopwatch dial hands move improperly, pull Crown to second click to reset watch



When buttons are released, the SECONDS dial turns 30 seconds counterclockwise and returns to the original position indicating the watch is reset to factory condition

TRIAx ARMORED II
super & regular



H2O RESIST

100m

Material Specifications

CRYSTAL

Mineral Glass

STRAP

Solid Stainless Steel

CASE

Stainless Steel

CASEBACK

Stainless Steel

BUCKLE

Stainless Steel

Battery

CHRONO

SR920SW Silver Oxide

SUPER

SR920SW Silver Oxide

REGULAR

SR621SW Silver Oxide

Battery Replacement

Do not open watch back.

Battery replacement must be performed by a certified Nike service center to retain a valid warranty. In addition to battery replacement, the service center will test movement, gaskets, water resistance and hardware, to further ensure the long-term care of your watch.

Warning! Keep watch batteries away from children.
If swallowed, contact a doctor immediately.

Warning! Batteries contain chemical substances.
They should be disposed of properly according to local regulations.