






# TIME


In TIME mode you can set time and calendar information.




**Time Warp**  
Hold for 1 second  
in any other mode to  
return to TIME.




**Switch Time Zones**



**Chime On/Off**




**Save Date, Time and Altitude  
to DATA mode**




# ALARM


In ALARM mode you can set alarms for 2 time zones, altitude and temperature.  
 Press any button to stop alarm. Time alarm will sound for 55 seconds.  
 Altitude and temperature alarms will sound for 5 seconds.



## Alarm On/Off





## Turn Off All Alarms




# S-RUN

In SKI RUN mode you can automatically time your ski run by marking your base altitude.




# CHRON

The CHRONOGRAPH can be used to time any activity down to 1/100th of a second.






# ALT 1


In ALTITUDE mode you can view, store and calibrate your current altitude; view and reset your maximum and accumulated altitudes.



Altitude, & feet/meters traveled per minute, Maximum Altitude, Accumulated and On Demand Altitude Reading.




Save Date, Time and Altitude to DATA mode




# WEATH

WEATHER mode provides a barometer, thermometer, and barometric weather forecaster.

Celsius/Farenheit  
hPa/inchHg




Set Current Weather



View Forecast and  
Barometric Pressure


*Falling Pressure: Clear weather is likely*

*Rising Pressure: Clouds/precipitation is likely*



# DATA

In DATA mode you can review  
date, time, and altitude. Save in  
ALTITUDE or TIME mode.



Data Auto Scrolls